Click to verify

Cell phone signal booster are designed to amplify your 5G and 4G LTE signals to improve your cell reception and eliminate dropped phone calls. Proper installation ensures you receive the best cell signal coverage in your home, office, or vehicle. On the other hand, improper installation will negatively affect your coverage area and uplink power. The installation process consists of multiple simple steps. Let's take a look at how to install a home, car, and RV cell phone signal booster. How to Install a Home Signal Booster Installing a home cell phone booster is not a difficult task, you don't have to be a professional cellular signal booster installer to get the job done. If you decide to go the DIY route, you will need a few tools: a ladder, your smartphone, a Phillips-head screwdriver, and an adjustable wrench. Step 1: Find the Best Cellular Signal Outside your Home Cell phone signal boosters, also known as repeaters and extenders, utilize an outdoor antenna to grab the existing weak signal. Its location can affect the strength of the signal that is being transmitted. Therefore, you will want the antenna to be located in an area with the strongest signal. So, before installing the antenna, it's extremely important to find the area with the best signal. Test the outside signal by walking around your home and using: Your phone's signal bars: The side of your home that provides the most bars will be the area where you should install the antenna. However, it's important to note that even though phone bars are a good way to see signal strength, they are subjective measurements. One bar for Verizon, 3 for AT&T, and 2 for T-Mobile. This happens because there is no standard on the level of signal strength each bar represents. dBm measurements: Using dBm measurements will provide you with the most accurate signal strength readings. Mobile signal can range from -50 to -120 dBm, with -50 dBm representing full bars and -120 dBm representing no signal. The side of your home that gives you the highest dBm measurement will be where you want to install your antenna. You can see your dBm measurement through the setting of your Android device or the Field Test Mode menu on iPhone's. Finding dB Readings on Your Phone Make sure you are not connected to WiFi or a Hotspot → Dial *3001#12345#* → Press the Call Button → Field Test Menu will Appear → Drag Down Notifications Bar → dBm reading will be displayed on the left-hand corner Go to Settings → About Phone → Network or Status → SIM Card Status → Signal Strength Step 2: Installing the Outside Antenna The outdoor antenna (also known as a donor antenna) should be installed as high as possible, ideally on the roof of your house. Doing so will improve the antenna's line of sight with the cell phone tower, as well as reduce the number of obstacles between the antenna and the tower that can degrade the signal. You can use a mounting pole, a vent pipe, or fascia to mount the antenna. This is where the ladder, Philips-head screwdriver, and adjustable wrench will come in handy. It's recommended to place the antenna on or near the edge of the roof. If you're using a directional antenna, such as a yagi antenna, make sure to point it away from your roof and in the direction of the nearest cell tower provided by your carrier. There is no need to aim an omnidirectional antenna. In situations where installing the antenna on the roof is impractical, you can mount it in the attic, on a wall, or near a window facing the cell tower. Keep in mind that the added obstructions can degrade the signal the antenna will be receiving. As a result, the amplifier will be receiving less signal, which can reduce the coverage area. Step 3: Connecting the Outdoor Antenna to the Amplifier After the antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside your home. This can be done in multiple ways: Drilling a hole into your house Following your satellite TV antenna cable and running the coax cable alongside it and into your house Running the cable through a vent Use a flat window entry cable and run it underneath the window Whichever method you decide to use, it's recommended to put a drip loop in your cable before it enters the house. A drip loop is a low point or a loop on the cable forcing the water to drip off and preventing it from entering your home. Once the cable is inside, connect it to the signal amplifier. Step 4: Installing the Inside Antenna Ideally, the inside antenna should be installed in or near the area where you are experiencing connectivity issues. Cell phone signal booster kits can consist of different types of indoor antennas: Dome Antenna: This antenna is ceiling mounted and will distribute a signal in a 360-degree angle. Panel Antenna: Usually, this antenna is wall-mounted, but it can also be ceiling mounted (make sure it's facing down). Panel antennas distribute a single in a 45 to 70-degree angle, meaning the signal will be strongest in the areas closest to it. Desktop Antenna: These antennas can be placed on any flat surface. Some booster kits, like the weBoost Home Room, consist of a stand-alone desktop antenna, while others, like the SureCall Flare 4G 3.0, or HiBoost Home 4K Plus, feature a 2-in-1 amplifier/antenna combo. When installing the inside antenna, make sure there is at least a distance of 20 feet vertical or 50 feet horizontal between the outside and inside antennas to prevent oscillation, which will cause the booster to shut down. After placing the antenna in the area where you need a better signal, connect the coaxial cable that was included in the box to the antenna and the amplifier (excluding amplifier/antenna combos). Step 5: Power On To complete the cell phone signal booster installation process, connect the power cord to the amplifier and a wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, the green lights on the booster mark the end of poor reception and dropped calls. If at any point in time you wanted to adjust the equipment's location or troubleshoot the amplifier, simply unplug the power cord, and plug it back in after a few seconds. Similar to how you would restart a router to reset your wireless signal. Alternative: Professionally Installed Cell Signal Boosters If the idea of installing a signal booster in your home or small business has you down, we offer a number of signal boosters which include professional installation as a part of the package. weBoost Installed Home Complete - 474445 Buy Now at $1299.99 Buy this Cell Phone Signal Booster If: You want to have your booster professionally installed. You live in a large home with strong outdoor signal and want whole home coverage. You live in a midsize home with weak outdoor signal and want whole home coverage. The weBoost Installed Home Complete is made to cover an entire home. It comes with free professional installation in virtually every zip code in the country. It can cover a large home with decent outside signal or a midsize home with weak outdoor signal. It can give up to 7,500 square feet of coverage with perfect outside signal. Most people will probably see a coverage area of between 3,500 and 5,500 square feet. If you want to cover more than one floor, you should buy more antennas. If you live in a very weak signal rural area you might get about 2,000 square feet of coverage from it. The weBoost Installed Home Complete is the only cellular amplifier we have that comes with free installation right now. If you do not think you can install a signal booster, buy this one. The installation is only available for residential buildings. For commercial buildings, check out the WilsonPro line, and the weBoost Office 300 Installed. weBoost Office 300 Installed Buy Now at $3799.99 Buy this Cell Phone Signal Booster If: You have a large office or commercial space. You want total carrier coverage in your business. You want a booster that's professionally installed. The weBoost Office 300 Installed is a commercial-grade booster for small to medium businesses. It can cover up to 15,000 square feet under best conditions, and comes with professional installation by OnTech. Equipped with a high-gain omnidirectional outdoor antenna and two low-profile indoor antennas, it offers incredible reach to distant cell towers and wider coverage. Whether your business is in the city or the countryside, the weBoost Office 300 Installed ensures reliable connectivity through your office building or in key areas. Commercial Installation Services In addition to WilsonPro installation, our nationwide team also offers Nextivity Cel-Fi installation. How to Install a Car Signal Booster Installing a vehicle signal booster is fast and simple. You won't be needing any tools. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your vehicle, as long as it's properly ventilated. Most people place the amplifier under a seat, but it can also be mounted to a seat. Step 2: Installing the Outside Antenna Most vehicle boosters feature a magnetic mount antenna, making them extremely easy to set up on a car, truck, or SUV. Simply place the external antenna on the roof of your vehicle, and voila. For optimal performance, the antenna should be at least 6 inches away from any windows and at least 1 foot away from any other antennas on your vehicle's roof. Run the cable below a door's weather seal and connect it to the amplifier. Note for new Ford owners or other cars made of aluminum: The antenna will not magnetically attach to an aluminum roof. You'll need to use stickem to attach the outside antenna. Step 3: Installing the Inside Antenna Low-profile antennas are the most common in-vehicle antennas. They can easily be Velcroed vertically or horizontally to the dashboard or a seat. Cradle antennas, on the other hand, are installed on your vehicle's air vent. Regardless of which antenna your booster uses, it must be installed at least 8 inches away from any person. After the antenna has been installed, connect the antenna's cable to the amplifier. Step 4: Power On To complete the vehicle booster's installation, connect the DC power supply to the booster and the auxiliary power outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. How to Install an RV Signal Booster Installing an RV signal booster is not hard. The most difficult step is installing the outside antenna. You'll be needing a Phillips-head screwdriver and an adjustable wrench. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your RV, as long as it's properly ventilated and close to a power outlet. It can be mounted on a wall, placed on a counter, or inside a cabinet. Step 2: Installing the Outside Antenna RV outside antennas need to be securely mounted on the roof. It can be easily attached to the RV's ladder or railing support post. Most RV boosters use omni antennas. For optimal results, mount the antenna vertically, do not mount it horizontally or at an angle. Doing so will degrade the booster's performance. Similar to a home booster, the higher you can get the antenna the better. This will improve the line of sight between the antenna and the cell tower, as well as reduce the number of cell phone signal blocking material. Just make sure the antenna is below the maximum height allowed in your state. Step 3: Connecting the Outdoor Antenna to the Amplifier After the external antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside the RV. This can be done by drilling a hole on the roof or wall and weatherproofing it later, or rerouting the cable through an existing entry point. After connecting the cable to the booster, make sure to secure the cable outside with cable clips or cable tie mounts. Step 4: Installing the Inside Antenna The inside antenna should be installed in the area where you wish to improve your cell signal. RV boosters, like the HiBoost Travel 4G 2.0 RV LTE and the weBoost Drive Reach RV, utilize desktop antennas to improve the signal indoors, while others, like the Cel-Fi Go+ and the SureCall Fusion2Go 3.0 RV 4G, use low-profile antennas or inside whip antennas. Desktop antennas are extremely easy to set up. Simply place the antenna on any flat surface. Low-profile antennas can easily be Velcroed vertically or horizontally to the dashboard or a seat. Inside whip antenna connects directly to the amplifier. For optimal results, make sure it's in an upright position. After placing the antenna in the area where you wish to improve your signal, connect the antenna's cable to the amplifier (excluding the inside whip antenna). Step 5: Power On To complete the RV booster's installation, connect the AC/DC power supply to the booster and the auxiliary power outlet or wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. Contact Us Signal Boosters is a leading provider of FCC-approved cell phone signal boosters for homes, vehicles, and commercial buildings. We believe everyone should enjoy great cell phone signal. That is our goal. We provide lifetime support and 2-3 year warranty on all of our signal boosters. Call us, and we will assist with any issues you might be experiencing with poor cell service. Contact us today, or call us at 1-800-470-6777. Interested in Learning More? Check Out Our Cellular Info Hub / WiFi Info Hub One of the most common concerns our customers have is whether or not their signal booster will be difficult to install. While installation is a multi-step process, each of these steps are simple on their own. Your booster manual provides a nice starting point for your individual installation, but we're here to help with a step-by-step breakdown all the same. Proper installation can greatly increase the coverage area of your cellular signal amplifier, so it's well worth the effort. Learn more about our WilsonPro installers. There are five main steps to installing a home signal booster system: Find the Best Outside Signal Install Outdoor Antenna. Connect to the Amplifier. Install Inside Antenna. Power on. The most "difficult" part is installing the outside antenna, whether a yagi directional antenna or an omni antenna. This requires climbing onto your roof, mounting the antenna, weatherproofing, and running cable into your home. You also need some tools, but nothing unusual. A ladder, your smartphone, a Phillips-head screwdriver, an adjustable wrench, and a little bit of elbow grease - and you'll be enjoying better cellular signal in no time! Let's start! 01. Find the Best Outside Signal Start by finding the best signal outside your home. Locating the side of your home with the best signal is the MOST CRUCIAL step of the installation process. This is done by walking around the perimeter of your home and either using the number of bars on your phone (ok method), smartphone apps (good method), or Field Test Mode (great method). Check out our blog on How to Read Cell Phone Signal Strength the Right Way for more on testing signal strength. 02. Install Outside Antenna Mount the outdoor antenna in the area where you have the best signal. Place the antenna as high as possible - ideally on the roof with a mounting pole, although the fascia or gable is acceptable. It's important that the outside antenna should be on or near the edge of the roof. If it's a yagi antenna, it should be pointing away from the house toward your nearest cell tower. See our guide on Finding Cell Tower Locations for the optimal way to point your antenna. 03. Connect to Signal Amplifier Once the outside antenna is mounted, connect a coaxial cable (one will be included in your booster kit) to the outside antenna and run it into your home where you keep your amplifier. Some run cable into the attic, others prefer using the window entry cable. Pick whichever works best for you, and ensure your amplifier is stored in a well-ventilated area. 04. Install Inside Antenna Figure out where in your home you need signal the most, and place the indoor antenna either on the wall (if a panel antenna) or on the ceiling (if a dome antenna) in that area. Run the other included cable to the amplifier (also called repeater). Make sure there is at least 20 feet vertical or 50 feet horizontal distance between the outside and inside antennas to prevent oscillation, which will cause your cell signal booster to automatically shut down. 05. Power On Plug in the power supply to the signal amplifier and to the wall outlet. The amplifier will sync up and if you see all green lights, you're in business. Check near the inside antenna how much boosted signal you're getting. Any post-installation adjustments will require rebooting the amplifier - simply unplug the power supply for 5-10 seconds (much like resetting your WiFi router) and plug it back in to reboot the system. And that's it! Enjoy your boosted mobile signal! Alternatives to DIY: Professionally Installed Signal Boosters If the entire idea of installing a signal booster in your home has you down, you're in luck: the weBoost Installed Home Complete comes with professional installation included. A team of experts will set an appointment to come into your home and install the signal booster for you. Performing the installation yourself has its perks - you are able to have greater control of the antennas, cables, and accessories and layout of your booster system - but if you don't have the mechanical know-how, or you just don't want to spend your time, then an installed booster is for you. How May We Help You? Wilson Amplifiers is the leading provider of signal boosters by weBoost and WilsonPro. Cell phone boosters are FCC approved devices that amplify 5G, 4G, and LTE cell phone signal for any phone with any carrier (including Verizon, AT&T, T-Mobile, US Cellular, and more) for home, office, or vehicle. We seriously hate dropped calls and poor coverage, so it's our goal to eliminate weak signal from your life: Free consultation (ask us anything) with our US-based customer support (sales@wilsonamplifiers.com) or call us at 1-800-568-2723 . Free shipping. Better signal or industry-leading 90 money-back guaranteed. No questions asked. We want everyone to be satisfied, so we provide lifetime technical support and a 2-year warranty for all products. Ask us anything and we'll be glad to help. Interested in Learning More? Check Out Our Signal Boosting Info Center THE WILSON AMPLIFIERS ADVANTAGE FREE SHIPPING No Minimum Purchase 90-DAY Money Back Guarantee LIFETIME Technical Support Cell phone signal booster are designed to amplify your 5G and 4G LTE signals to improve your cell reception and eliminate dropped phone calls. Proper installation ensures you receive the best cell signal coverage in your home, office, or vehicle. On the other hand, improper installation will negatively affect your coverage area and uplink power. The installation process consists of multiple simple steps. Let's take a look at how to install a home, car, and RV cell phone signal booster. How to Install a Home Signal Booster Installing a home cell phone booster is not a difficult task, you don't have to be a professional cellular signal booster installer to get the job done. If you decide to go the DIY route, you will need a few tools: a ladder, your smartphone, a Phillips-head screwdriver, and an adjustable wrench. Step 1: Find the Best Cellular Signal Outside your Home Cell phone signal boosters, also known as repeaters and extenders, utilize an outdoor antenna to grab the existing weak signal. Its location can affect the strength of the signal that is being transmitted. Therefore, you will want the antenna to be located in an area with the strongest signal. So, before installing the antenna, it's extremely important to find the area with the best signal. Test the outside signal by walking around your home and using: Your phone's signal bars: The side of your home that provides the most bars will be the area where you should install the antenna. However, it's important to note that even though phone bars are a good way to see signal strength, they are subjective measurements. One bar for Verizon, 3 for AT&T, and 2 for T-Mobile. This happens because there is no standard on the level of signal strength each bar represents. dBm measurements: Using dBm measurements will provide you with the most accurate signal strength readings. Mobile signal can range from -50 to -120 dBm, with -50 dBm representing full bars and -120 dBm representing no signal. The side of your home that gives you the highest dBm measurement will be where you want to install your antenna. You can see your dBm measurement through the setting of your Android device or the Field Test Mode menu on iPhone's. Finding dB Readings on Your Phone Make sure you are not connected to WiFi or a Hotspot → Dial *3001#12345#* → Press the Call Button → Field Test Menu will Appear → Drag Down Notifications Bar → dBm reading will be displayed on the left-hand corner Go to Settings → About Phone → Network or Status → SIM Card Status → Signal Strength Step 2: Installing the Outside Antenna The outdoor antenna (also known as a donor antenna) should be installed as high as possible, ideally on the roof of your house. Doing so will improve the antenna's line of sight with the cell phone tower, as well as reduce the number of obstacles between the antenna and the tower that can degrade the signal. You can use a mounting pole, a vent pipe, or fascia to mount the antenna. This is where the ladder, Philips-head screwdriver, and adjustable wrench will come in handy. It's recommended to place the antenna on or near the edge of the roof. If you're using a directional antenna, such as a yagi antenna, make sure to point it away from your roof and in the direction of the nearest cell tower provided by your carrier. There is no need to aim an omnidirectional antenna. In situations where installing the antenna on the roof is impractical, you can mount it in the attic, on a wall, or near a window facing the cell tower. Keep in mind that the added obstructions can degrade the signal the antenna will be receiving. As a result, the amplifier will be receiving less signal, which can reduce the coverage area. Step 3: Connecting the Outdoor Antenna to the Amplifier After the antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside your home. This can be done in multiple ways: Drilling a hole into your house Following your satellite TV antenna cable and running the coax cable alongside it and into your house Running the cable through a vent Use a flat window entry cable and run it underneath the window Whichever method you decide to use, it's recommended to put a drip loop in your cable before it enters the house. A drip loop is a low point or a loop on the cable forcing the water to drip off and preventing it from entering your home. Once the cable is inside, connect it to the signal amplifier. Step 4: Installing the Inside Antenna Ideally, the inside antenna should be installed in or near the area where you are experiencing connectivity issues. Cell phone signal booster kits can consist of different types of indoor antennas: Dome Antenna: This antenna is ceiling mounted and will distribute a signal in a 360-degree angle. Panel Antenna: Usually, this antenna is wall-mounted, but it can also be ceiling mounted (make sure it's facing down). Panel antennas distribute a single in a 45 to 70-degree angle, meaning the signal will be strongest in the areas closest to it. Desktop Antenna: These antennas can be placed on any flat surface. Some booster kits, like the weBoost Home Room, consist of a stand-alone desktop antenna, while others, like the SureCall Flare 4G 3.0, or HiBoost Home 4K Plus, feature a 2-in-1 amplifier/antenna combo. When installing the inside antenna, make sure there is at least a distance of 20 feet vertical or 50 feet horizontal between the outside and inside antennas to prevent oscillation, which will cause the booster to shut down. After placing the antenna in the area where you need a better signal, connect the coaxial cable that was included in the box to the antenna and the amplifier (excluding amplifier/antenna combos). Step 5: Power On To complete the cell phone signal booster installation process, connect the power cord to the amplifier and a wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, the green lights on the booster mark the end of poor reception and dropped calls. If at any point in time you wanted to adjust the equipment's location or troubleshoot the amplifier, simply unplug the power cord, and plug it back in after a few seconds. Similar to how you would restart a router to reset your wireless signal. Alternative: Professionally Installed Cell Signal Boosters If the idea of installing a signal booster in your home or small business has you down, we offer a number of signal boosters which include professional installation as a part of the package. weBoost Installed Home Complete - 474445 Buy Now at $1299.99 Buy this Cell Phone Signal Booster If: You want to have your booster professionally installed. You live in a large home with strong outdoor signal and want whole home coverage. You live in a midsize home with weak outdoor signal and want whole home coverage. The weBoost Installed Home Complete is made to cover an entire home. It comes with free professional installation in virtually every zip code in the country. It can cover a large home with decent outside signal or a midsize home with weak outdoor signal. It can give up to 7,500 square feet of coverage with perfect outside signal. Most people will probably see a coverage area of between 3,500 and 5,500 square feet. If you want to cover more than one floor, you should buy more antennas. If you live in a very weak signal rural area you might get about 2,000 square feet of coverage from it. The weBoost Installed Home Complete is the only cellular amplifier we have that comes with free installation right now. If you do not think you can install a signal booster, buy this one. The installation is only available for residential buildings. For commercial buildings, check out the WilsonPro line, and the weBoost Office 300 Installed. weBoost Office 300 Installed Buy Now at $3799.99 Buy this Cell Phone Signal Booster If: You have a large office or commercial space. You want total carrier coverage in your business. You want a booster that's professionally installed. The weBoost Office 300 Installed is a commercial-grade booster for small to medium businesses. It can cover up to 15,000 square feet under best conditions, and comes with professional installation by OnTech. Equipped with a high-gain omnidirectional outdoor antenna and two low-profile indoor antennas, it offers incredible reach to distant cell towers and wider coverage. Whether your business is in the city or the countryside, the weBoost Office 300 Installed ensures reliable connectivity through your office building or in key areas. Commercial Installation Services In addition to WilsonPro installation, our nationwide team also offers Nextivity Cel-Fi installation. How to Install a Car Signal Booster Installing a vehicle signal booster is fast and simple. You won't be needing any tools. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your vehicle, as long as it's properly ventilated. Most people place the amplifier under a seat, but it can also be mounted to a seat. Step 2: Installing the Outside Antenna Most vehicle boosters feature a magnetic mount antenna, making them extremely easy to set up on a car, truck, or SUV. Simply place the external antenna on the roof of your vehicle, and voila. For optimal performance, the antenna should be at least 6 inches away from any windows and at least 1 foot away from any other antennas on your vehicle's roof. Run the cable below a door's weather seal and connect it to the amplifier. Note for new Ford owners or other cars made of aluminum: The antenna will not magnetically attach to an aluminum roof. You'll need to use stickem to attach the outside antenna. Step 3: Installing the Inside Antenna Low-profile antennas are the most common in-vehicle antennas. They can easily be Velcroed vertically or horizontally to the dashboard or a seat. Cradle antennas, on the other hand, are installed on your vehicle's air vent. Regardless of which antenna your booster uses, it must be installed at least 8 inches away from any person. After the antenna has been installed, connect the antenna's cable to the amplifier. Step 4: Power On To complete the vehicle booster's installation, connect the DC power supply to the booster and the auxiliary power outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. How to Install an RV Signal Booster Installing an RV signal booster is not hard. The most difficult step is installing the outside antenna. You'll be needing a Phillips-head screwdriver and an adjustable wrench. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your RV, as long as it's properly ventilated and close to a power outlet. It can be mounted on a wall, placed on a counter, or inside a cabinet. Step 2: Installing the Outside Antenna RV outside antennas need to be securely mounted on the roof. It can be easily attached to the RV's ladder or railing support post. Most RV boosters use omni antennas. For optimal results, mount the antenna vertically, do not mount it horizontally or at an angle. Doing so will degrade the booster's performance. Similar to a home booster, the higher you can get the antenna the better. This will improve the line of sight between the antenna and the cell tower, as well as reduce the number of cell phone signal blocking material. Just make sure the antenna is below the maximum height allowed in your state. Step 3: Connecting the Outdoor Antenna to the Amplifier After the external antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside the RV. This can be done by drilling a hole on the roof or wall and weatherproofing it later, or rerouting the cable through an existing entry point. After connecting the cable to the booster, make sure to secure the cable outside with cable clips or cable tie mounts. Step 4: Installing the Inside Antenna The inside antenna should be installed in the area where you wish to improve your cell signal. RV boosters, like the HiBoost Travel 4G 2.0 RV LTE and the weBoost Drive Reach RV, utilize desktop antennas to improve the signal indoors, while others, like the Cel-Fi Go+ and the SureCall Fusion2Go 3.0 RV 4G, use low-profile antennas or inside whip antennas. Desktop antennas are extremely easy to set up. Simply place the antenna on any flat surface. Low-profile antennas can easily be Velcroed vertically or horizontally to the dashboard or a seat. Inside whip antenna connects directly to the amplifier. For optimal results, make sure it's in an upright position. After placing the antenna in the area where you wish to improve your signal, connect the antenna's cable to the amplifier (excluding the inside whip antenna). Step 5: Power On To complete the RV booster's installation, connect the AC/DC power supply to the booster and the auxiliary power outlet or wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. Contact Us Signal Boosters is a leading provider of FCC-approved cell phone signal boosters for homes, vehicles, and commercial buildings. We believe everyone should enjoy great cell phone signal. That is our goal. We provide lifetime support and 2-3 year warranty on all of our signal boosters. Call us, and we will assist with any issues you might be experiencing with poor cell service. Contact us today, or call us at 1-800-470-6777. Interested in Learning More? Check Out Our Cellular Info Hub / WiFi Info Hub Welcome to the step-by-step guide for installing a cell phone signal booster. In today's fast-paced world, a reliable cell phone signal is crucial for staying connected, whether it's for work, emergencies, or simply keeping in touch with loved ones. Unfortunately, weak or unreliable signals can be a frustrating reality, especially in remote areas or buildings with thick walls. However, with a cell phone signal booster, you can significantly improve your signal strength and call quality. Installing a cell phone signal booster may seem daunting at first, but with the right guidance and a clear understanding of the process, you can easily set up the booster and enjoy a stronger, more reliable signal. This guide will walk you through each step, from selecting the right booster for your needs to testing the signal booster to ensure optimal performance. Whether you're a homeowner, business owner, or simply someone looking to improve their cell phone signal, this guide will provide you with the knowledge and confidence to install a cell phone signal booster successfully. So, let's dive in and get started on boosting your cell phone signal! Step 1: Choosing the Right Cell Phone Signal Booster Before embarking on the installation process, it's crucial to select the right cell phone signal booster for your specific needs. There are various factors to consider when choosing a booster, including the size of the area you need to cover, the strength of the outside signal, and the number of users who will rely on the boosted signal. Consider the Coverage Area: Determine the square footage of the area where you need improved signal strength. Whether it's a small office, a large warehouse, or a multi-story home, there are signal boosters designed to cover different sizes of spaces. Be sure to choose a booster that can adequately cover the entire area. Evaluate Outside Signal Strength: Understanding the strength of the outside signal in the location where you plan to install the outdoor antenna is crucial. This can be done using a cell phone in test mode or with a signal meter. The strength of the outside signal will help determine the type and power of the booster you need to effectively amplify the signal indoors. Consider the Number of Users: If multiple users will be relying on the boosted signal, it's important to choose a booster that can accommodate the expected user load. Some boosters are designed to support multiple simultaneous connections, making them ideal for busy offices or homes with several occupants. Additionally, consider whether you need a booster for voice calls only, or if you also require improved data speeds for internet connectivity. There are boosters designed specifically for data, voice, or both, so be sure to select a booster that aligns with your specific communication needs. By carefully considering these factors, you can choose a cell phone signal booster that is tailored to your unique requirements, ensuring that you achieve the best possible signal enhancement for your specific environment. Step 2: Finding the Best Location for the Outdoor Antenna Once you've selected the appropriate cell phone signal booster for your needs, the next crucial step is to determine the optimal location for the outdoor antenna. The outdoor antenna plays a pivotal role in capturing the existing outside signal and transmitting it to the booster unit for amplification. Finding the best location for the outdoor antenna is essential for maximizing the booster's effectiveness. Identify the Direction of the Nearest Cell Tower: Understanding the direction of the nearest cell tower can help you position the outdoor antenna for optimal signal reception. You can use online tools or mobile apps to locate nearby cell towers and their respective directions. By aligning the outdoor antenna towards the nearest tower, you can ensure that it captures the strongest possible signal. Consider Obstructions and Interference: Assess the surrounding environment for potential obstructions and sources of interference that could hinder the outdoor antenna's ability to capture the outside signal. Trees, buildings, and other structures can obstruct the signal path, so it's important to position the outdoor antenna in a location with minimal obstructions to ensure unimpeded signal reception. Evaluate Mounting Options: Depending on your specific installation environment, you may have various mounting options for the outdoor antenna, such as roof mounts, pole mounts, or wall mounts. Consider the structural integrity of the mounting location and ensure that it provides a clear line of sight to the nearest cell tower for optimal signal reception. Furthermore, it's essential to adhere to local regulations and building codes when installing the outdoor antenna. Some areas may have restrictions on antenna placement and height, so it's important to comply with any applicable guidelines to ensure a compliant and effective installation. By carefully assessing the direction of the nearest cell tower, mitigating potential obstructions, and selecting the most suitable mounting option, you can determine the best location for the outdoor antenna, setting the stage for a successful cell phone signal booster installation. Step 3: Installing the Outdoor Antenna With the optimal location for the outdoor antenna identified, the next step is to proceed with the installation process. Installing the outdoor antenna correctly is crucial for ensuring that it effectively captures the existing outside signal and facilitates the transmission of the signal to the booster unit. Here's a step-by-step guide to installing the outdoor antenna: Gather the Necessary Tools: Before beginning the installation, gather the required tools, including a mounting bracket, screws, a drill, a wrench, and any additional mounting hardware specific to your chosen installation location. Assemble the Outdoor Antenna: Follow the manufacturer's instructions to assemble the outdoor antenna and attach it to the mounting bracket securely. Ensure that all components are properly connected and tightened to prevent any potential issues once the antenna is installed. Securely Mount the Antenna: Depending on the chosen mounting option, securely mount the outdoor antenna in the predetermined location. Use appropriate fasteners and mounting hardware to ensure the antenna is stable and positioned according to the optimal direction for signal reception. Route the Cable to the Booster Unit: Once the outdoor antenna is securely mounted, carefully route the coaxial cable from the antenna to the location of the booster unit. Ensure that the cable is protected from potential damage and is routed efficiently to minimize signal loss. Ground the Antenna (If Required): In some installations, grounding the outdoor antenna may be necessary to comply with local regulations and ensure electrical safety. Follow the manufacturer's guidelines and any applicable regulations to properly ground the antenna for safe and compliant operation. Throughout the installation process, it's essential to prioritize safety and precision to ensure that the outdoor antenna is installed securely and in a manner that optimizes signal reception. By following these steps and adhering to the manufacturer's guidelines, you can successfully install the outdoor antenna, bringing you one step closer to experiencing improved cell phone signal strength and reliability. Step 4: Placing the Indoor Antenna Once the outdoor antenna is successfully installed, the next critical step in the cell phone signal booster installation process is placing the indoor antenna. The indoor antenna is responsible for distributing the boosted signal within the designated coverage area, ensuring that users can experience improved signal strength and call quality throughout the space. Here's how to effectively place the indoor antenna: Identify the Ideal Indoor Location: Assess the layout of the coverage area and identify a central location where the indoor antenna can effectively distribute the boosted signal. Consider areas with high user activity and ensure that the antenna's placement allows for optimal signal coverage throughout the space. Mount or Position the Indoor Antenna: Depending on the type of indoor antenna included with your signal booster kit, you may have options for mounting the antenna on a wall, placing it on a flat surface, or positioning it in an elevated location. Follow the manufacturer's recommendations for the best placement method based on the antenna type. Ensure Proper Antenna Orientation: Some indoor antennas have directional characteristics, so it's essential to orient the antenna according to the manufacturer's guidelines to achieve the best signal distribution. Proper antenna orientation can maximize signal coverage and ensure consistent signal strength throughout the coverage area. Connect the Indoor Antenna to the Booster Unit: Once the indoor antenna is positioned in the ideal location, connect it to the booster unit using the provided coaxial cable. Ensure that the connection is secure and that the cable routing minimizes signal loss and interference to maintain optimal signal distribution. Consider Multiple Antenna Options: In larger or multi-level spaces, it may be beneficial to use multiple indoor antennas to ensure comprehensive signal coverage. Some signal booster kits offer the option to connect multiple indoor antennas to the booster unit, providing enhanced signal distribution throughout the area. By carefully selecting the indoor antenna's placement, ensuring proper orientation, and connecting it to the booster unit as directed, you can effectively distribute the boosted signal throughout the coverage area, providing consistent and reliable cell phone signal strength to all users within the designated space. Step 5: Connecting the Booster and Powering Up With the outdoor and indoor antennas in place, the next crucial step in the cell phone signal booster installation process is connecting the booster unit and powering up the system. Properly connecting the booster and ensuring that it receives power is essential for activating the signal amplification process and providing enhanced signal strength throughout the coverage area. Here's how to connect the booster and power up the system: Connect the Outdoor Antenna to the Booster: Use the provided coaxial cable to connect the outdoor antenna to the designated port on the booster unit. Ensure that the connection is secure and that the cable routing minimizes signal loss and interference to maintain

optimal signal transmission from the outdoor antenna to the booster. Connect the Indoor Antenna to the Booster: Similarly, use the provided coaxial cable to connect the indoor antenna to the booster unit. Ensure that the connection is secure and that the cable routing facilitates efficient signal distribution from the booster to the indoor antenna, allowing for consistent signal coverage throughout the designated area. Connect the Power Supply: Plug the power supply into the booster unit and connect it to a reliable power source. Ensure that the power supply is compatible with the booster unit and that the power source is stable and easily accessible for ongoing operation of the signal booster system. Power Up the Booster: Once all connections are secure, power up the booster unit according to the manufacturer's instructions. This typically involves turning on the power supply and allowing the booster to initialize and begin amplifying the incoming signal for improved distribution throughout the coverage area. Monitor the Booster Status: After powering up the booster, monitor the booster unit's status indicators to ensure that it is operating correctly and amplifying the signal as intended. Refer to the manufacturer's documentation to understand the meaning of different status indicators and troubleshoot any potential issues that may arise. By carefully connecting the outdoor and indoor antennas to the booster unit, ensuring a stable power supply, and powering up the booster according to the manufacturer's guidelines, you can activate the signal amplification process and provide enhanced cell phone signal strength within the designated coverage area. Step 6: Testing the Signal Booster Once the cell phone signal booster is installed and powered up, the final step in the installation process is to thoroughly test the booster to ensure that it is effectively enhancing the signal strength and providing reliable connectivity. Testing the signal booster allows you to verify its performance and make any necessary adjustments to optimize its operation. Here's how to test the signal booster: Conduct Signal Strength Tests: Using a cell phone or a signal meter, conduct signal strength tests throughout the coverage area to assess the improvement in signal quality and strength. Compare the signal strength and call quality before and after the booster installation to gauge the booster's effectiveness. Verify Coverage Area: Ensure that the boosted signal adequately covers the entire designated area, including all rooms, floors, or sections where reliable cell phone signal strength is essential. Identify any areas with weaker signal reception and consider potential adjustments to the antenna placement or booster settings to enhance coverage. Test Voice and Data Connectivity: Place test calls and assess data connectivity within the coverage area to ensure that the booster effectively enhances both voice and data communication. Verify that calls are clear and that data transfer speeds are improved, providing a seamless user experience for all cell phone users within the space. Optimize Antenna Placement (if necessary): If signal tests reveal areas with suboptimal signal strength, consider adjusting the placement of the outdoor and indoor antennas to improve signal coverage. Small adjustments to the antenna orientation or placement can significantly impact signal distribution and overall booster performance. Document Test Results: Document the results of the signal strength tests, including any areas of concern or notable improvements in signal quality. This documentation can serve as a reference for future troubleshooting or adjustments and provide valuable insights into the booster's impact on signal strength. By conducting comprehensive signal strength tests, verifying coverage area, testing voice and data connectivity, and documenting the test results, you can ensure that the signal booster is effectively enhancing cell phone signal strength and providing reliable connectivity throughout the designated space. Regular testing and monitoring of the booster's performance can help maintain optimal signal quality and address any potential issues proactively. Conclusion Congratulations on successfully completing the installation of your cell phone signal booster! By following this step-by-step guide, you have taken the necessary measures to improve your cell phone signal strength and ensure reliable connectivity within your designated coverage area. The installation process may initially seem daunting, but with the right guidance and attention to detail, you have empowered yourself to enjoy enhanced signal quality and improved communication capabilities. Choosing the right cell phone signal booster, identifying optimal locations for the outdoor and indoor antennas, and meticulously connecting and testing the booster are all essential steps in the process. By carefully considering factors such as coverage area, outside signal strength, and user load, you have selected a booster that aligns with your specific needs, setting the stage for a successful installation. As you tested the booster's performance and verified signal strength and coverage, you have gained valuable insights into the booster's impact on your communication capabilities. Whether it's making clear calls, enjoying faster data speeds, or simply staying connected without interruptions, the signal booster's effectiveness is now evident through your thorough testing. By documenting the test results and remaining mindful of potential adjustments to antenna placement or booster settings, you have positioned yourself to maintain optimal signal quality and address any future challenges proactively. Regular testing and monitoring of the booster's performance will ensure that you continue to benefit from reliable and enhanced cell phone signal strength in the long term. With the installation process complete and the booster successfully enhancing your signal strength, you can now enjoy the peace of mind that comes with consistent and reliable connectivity. Whether it's in your home, office, or any other designated space, the cell phone signal booster has empowered you to stay connected and communicate effectively, regardless of your location or the surrounding signal conditions. Thank you for embarking on this installation journey with us. We hope this guide has been instrumental in helping you achieve improved cell phone signal strength and a more seamless communication experience. Here's to enjoying uninterrupted connectivity and clear communication with your newly installed cell phone signal booster! Cell phone signal booster are designed to amplify your 5G and 4G LTE signals to improve your cell reception and eliminate dropped phone calls. Proper installation ensures you receive the best cell signal coverage in your home, office, or vehicle. On the other hand, improper installation will negatively affect your coverage area and uplink power. The installation process consists of multiple simple steps. Let's take a look at how to install a home, car, and RV cell phone signal booster. How to Install a Home Signal Booster Installing a home cell phone booster is not a difficult task, you don't have to be a professional cellular signal booster installer to get the job done. If you decide to go the DIY route, you will need a few tools: a ladder, your smartphone, a Phillips-head screwdriver, and an adjustable wrench. Step 1: Find the Best Cellular Signal Outside your Home Cell phone signal boosters, also known as repeaters and extenders, utilize an outdoor antenna to grab the existing weak signal. Its location can affect the strength of the signal that is being transmitted. Therefore, you will want the antenna to be located in an area with the strongest signal. So, before installing the antenna, it's extremely important to find the area with the best signal. Test the outside signal by walking around your home and using: Your phone's signal bars: The side of your home that provides the most bars will be the area where you should install the antenna. However, it's important to note that even though phone bars are a good way to see signal strength, they are subjective measurements. One bar for Verizon, 3 for AT&T, and 2 for T-Mobile. This happens because there is no standard on the level of signal strength each bar represents. dBm measurements: Using dBm measurements will provide you with the most accurate signal strength readings. Mobile signal can range from -50 to -120 dBm, with -50 dBm representing full bars and -120 dBm representing no signal. The side of your home that gives you the highest dBm measurement will be where you want to install your antenna. You can see your dBm measurement through the setting of your Android device or the Field Test Mode menu on iPhone's. Finding dB Readings on Your Phone Make sure you are not connected to WiFi or a Hotspot → Dial *3001#12345#* → Press the Call Button → Field Test Menu will Appear → Drag Down Notifications Bar → dBm reading will be displayed on the left-hand corner Go to Settings → About Phone → Network or Status → SIM Card Status → Signal Strength Step 2: Installing the Outside Antenna The outdoor antenna (also known as a donor antenna) should be installed as high as possible, ideally on the roof of your house. Doing so will improve the antenna's line of sight with the cell phone tower, as well as reduce the number of obstacles between the antenna and the tower that can degrade the signal. You can use a mounting pole, a vent pipe, or fascia to mount the antenna. This is where the ladder, Philips-head screwdriver, and adjustable wrench will come in handy. It's recommended to place the antenna on or near the edge of the roof. If you're using a directional antenna, such as a yagi antenna, make sure to point it away from your roof and in the direction of the nearest cell tower provided by your carrier. There is no need to aim an omnidirectional antenna. In situations where installing the antenna on the roof is impractical, you can mount it in the attic, on a wall, or near a window facing the cell tower. Keep in mind that the added obstructions can degrade the signal the antenna will be receiving. As a result, the amplifier will be receiving less signal, which can reduce the coverage area. Step 3: Connecting the Outdoor Antenna to the Amplifier After the antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside your home. This can be done in multiple ways: Drilling a hole into your house Following your satellite TV antenna cable and running the coax cable alongside it and into your house Running the cable through a vent Use a flat window entry cable and run it underneath the window Whichever method you decide to use, it's recommended to put a drip loop in your cable before it enters the house. A drip loop is a low point or a loop on the cable forcing the water to drip off and preventing it from entering your home. Once the cable is inside, connect it to the signal amplifier. Step 4: Installing the Inside Antenna Ideally, the inside antenna should be installed in or near the area where you are experiencing connectivity issues. Cell phone signal booster kits can consist of different types of indoor antennas: Dome Antenna: This antenna is ceiling mounted and will distribute a signal in a 360-degree angle. Panel Antenna: Usually, this antenna is wall-mounted, but it can also be ceiling mounted (make sure it's facing down). Panel antennas distribute a single in a 45 to 70-degree angle, meaning the signal will be strongest in the areas closest to it. Desktop Antenna: These antennas can be placed on any flat surface. Some booster kits, like the weBoost Home Room, consist of a stand-alone desktop antenna, while others, like the SureCall Flare 4G 3.0, or HiBoost Home 4K Plus, feature a 2-in-1 amplifier/antenna combo. When installing the inside antenna, make sure there is at least a distance of 20 feet vertical or 50 feet horizontal between the outside and inside antennas to prevent oscillation, which will cause the booster to shut down. After placing the antenna in the area where you need a better signal, connect the coaxial cable that was included in the box to the antenna and the amplifier (excluding amplifier/antenna combos). Step 5: Power On To complete the cell phone signal booster installation process, connect the power cord to the amplifier and a wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, the green lights on the booster mark the end of poor reception and dropped calls. If at any point in time you wanted to adjust the equipment's location or troubleshoot the amplifier, simply unplug the power cord, and plug it back in after a few seconds. Similar to how you would restart a router to reset your wireless signal. Alternative: Professionally Installed Cell Signal Boosters If the idea of installing a signal booster in your home or small business has you down, we offer a number of signal boosters which include professional installation as a part of the package. weBoost Installed Home Complete - 474445 Buy Now at $1299.99 Buy this Cell Phone Signal Booster If: You want to have your booster professionally installed. You live in a large home with strong outdoor signal and want whole home coverage. You live in a midsize home with weak outdoor signal and want whole home coverage. The weBoost Installed Home Complete is made to cover an entire home. It comes with free professional installation in virtually every zip code in the country. It can cover a large home with decent outside signal or a midsize home with weak outdoor signal. It can give up to 7,500 square feet of coverage with perfect outside signal. Most people will probably see a coverage area of between 3,500 and 5,500 square feet. If you want to cover more than one floor, you should buy more antennas. If you live in a very weak signal rural area you might get about 2,000 square feet of coverage from it. The weBoost Installed Home Complete is the only cellular amplifier we have that comes with free installation right now. If you do not think you can install a signal booster, buy this one. The installation is only available for residential buildings. For commercial buildings, check out the WilsonPro line, and the weBoost Office 300 Installed. weBoost Office 300 Installed Buy Now at $3799.99 Buy this Cell Phone Signal Booster If: You have a large office or commercial space. You want total carrier coverage in your business. You want a booster that's professionally installed. The weBoost Office 300 Installed is a commercial-grade booster for small to medium businesses. It can cover up to 15,000 square feet under best conditions, and comes with professional installation by OnTech. Equipped with a high-gain omnidirectional outdoor antenna and two low-profile indoor antennas, it offers incredible reach to distant cell towers and wider coverage. Whether your business is in the city or the countryside, the weBoost Office 300 Installed ensures reliable connectivity through your office building or in key areas. Commercial Installation Services In addition to WilsonPro installation, our nationwide team also offers Nextivity Cel-Fi installation. How to Install a Car Signal Booster Installing a vehicle signal booster is fast and simple. You won't be needing any tools. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your vehicle, as long as it's properly ventilated. Most people place the amplifier under a seat, but it can also be mounted to a seat. Step 2: Installing the Outside Antenna Most vehicle boosters feature a magnetic mount antenna, making them extremely easy to set up on a car, truck, or SUV. Simply place the external antenna on the roof of your vehicle, and voila. For optimal performance, the antenna should be at least 6 inches away from any windows and at least 1 foot away from any other antennas on your vehicle's roof. Run the cable below a door's weather seal and connect it to the amplifier. Note for new Ford owners or other cars made of aluminum: The antenna will not magnetically attach to an aluminum roof. You'll need to use stickem to attach the outside antenna. Step 3: Installing the Inside Antenna Low-profile antennas are the most common in-vehicle antennas. They can easily be Velcroed vertically or horizontally to the dashboard or a seat. Cradle antennas, on the other hand, are installed on your vehicle's air vent. Regardless of which antenna your booster uses, it must be installed at least 8 inches away from any person. After the antenna has been installed, connect the antenna's cable to the amplifier. Step 4: Power On To complete the vehicle booster's installation, connect the DC power supply to the booster and the auxiliary power outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. How to Install an RV Signal Booster Installing an RV signal booster is not hard. The most difficult step is installing the outside antenna. You'll be needing a Phillips-head screwdriver and an adjustable wrench. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your RV, as long as it's properly ventilated and close to a power outlet. It can be mounted on a wall, placed on a counter, or inside a cabinet. Step 2: Installing the Outside Antenna RV outside antennas need to be securely mounted on the roof. It can be easily attached to the RV's ladder or railing support post. Most RV boosters use omni antennas. For optimal results, mount the antenna vertically, do not mount it horizontally or at an angle. Doing so will degrade the booster's performance. Similar to a home booster, the higher you can get the antenna the better. This will improve the line of sight between the antenna and the cell tower, as well as reduce the number of cell phone signal blocking material. Just make sure the antenna is below the maximum height allowed in your state. Step 3: Connecting the Outdoor Antenna to the Amplifier After the external antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside the RV. This can be done by drilling a hole on the roof or wall and weatherproofing it later, or rerouting the cable through an existing entry point. After connecting the cable to the booster, make sure to secure the cable outside with cable clips or cable tie mounts. Step 4: Installing the Inside Antenna The inside antenna should be installed in the area where you wish to improve your cell signal. RV boosters, like the HiBoost Travel 4G 2.0 RV LTE and the weBoost Drive Reach RV, utilize desktop antennas to improve the signal indoors, while others, like the Cel-Fi Go+ and the SureCall Fusion2Go 3.0 RV 4G, use low-profile antennas or inside whip antennas. Desktop antennas are extremely easy to set up. Simply place the antenna on any flat surface. Low-profile antennas can easily be Velcroed vertically or horizontally to the dashboard or a seat. Inside whip antenna connects directly to the amplifier. For optimal results, make sure it's in an upright position. After placing the antenna in the area where you wish to improve your signal, connect the antenna's cable to the amplifier (excluding the inside whip antenna). Step 5: Power On To complete the RV booster's installation, connect the AC/DC power supply to the booster and the auxiliary power outlet or wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. Contact Us Signal Boosters is a leading provider of FCC-approved cell phone signal boosters for homes, vehicles, and commercial buildings. We believe everyone should enjoy great cell phone signal. That is our goal. We provide lifetime support and 2-3 year warranty on all of our signal boosters. Call us, and we will assist with any issues you might be experiencing with poor cell service. Contact us today, or call us at 1-800-470-6777. Interested in Learning More? Check Out Our Cellular Info Hub / WiFi Info Hub Cell phone signal booster are designed to amplify your 5G and 4G LTE signals to improve your cell reception and eliminate dropped phone calls. Proper installation ensures you receive the best cell signal coverage in your home, office, or vehicle. On the other hand, improper installation will negatively affect your coverage area and uplink power. The installation process consists of multiple simple steps. Let's take a look at how to install a home, car, and RV cell phone signal booster. How to Install a Home Signal Booster Installing a home cell phone booster is not a difficult task, you don't have to be a professional cellular signal booster installer to get the job done. If you decide to go the DIY route, you will need a few tools: a ladder, your smartphone, a Phillips-head screwdriver, and an adjustable wrench. Step 1: Find the Best Cellular Signal Outside your Home Cell phone signal boosters, also known as repeaters and extenders, utilize an outdoor antenna to grab the existing weak signal. Its location can affect the strength of the signal that is being transmitted. Therefore, you will want the antenna to be located in an area with the strongest signal. So, before installing the antenna, it's extremely important to find the area with the best signal. Test the outside signal by walking around your home and using: Your phone's signal bars: The side of your home that provides the most bars will be the area where you should install the antenna. However, it's important to note that even though phone bars are a good way to see signal strength, they are subjective measurements. One bar for Verizon, 3 for AT&T, and 2 for T-Mobile. This happens because there is no standard on the level of signal strength each bar represents. dBm measurements: Using dBm measurements will provide you with the most accurate signal strength readings. Mobile signal can range from -50 to -120 dBm, with -50 dBm representing full bars and -120 dBm representing no signal. The side of your home that gives you the highest dBm measurement will be where you want to install your antenna. You can see your dBm measurement through the setting of your Android device or the Field Test Mode menu on iPhone's. Finding dB Readings on Your Phone Make sure you are not connected to WiFi or a Hotspot → Dial *3001#12345#* → Press the Call Button → Field Test Menu will Appear → Drag Down Notifications Bar → dBm reading will be displayed on the left-hand corner Go to Settings → About Phone → Network or Status → SIM Card Status → Signal Strength Step 2: Installing the Outside Antenna The outdoor antenna (also known as a donor antenna) should be installed as high as possible, ideally on the roof of your house. Doing so will improve the antenna's line of sight with the cell phone tower, as well as reduce the number of obstacles between the antenna and the tower that can degrade the signal. You can use a mounting pole, a vent pipe, or fascia to mount the antenna. This is where the ladder, Philips-head screwdriver, and adjustable wrench will come in handy. It's recommended to place the antenna on or near the edge of the roof. If you're using a directional antenna, such as a yagi antenna, make sure to point it away from your roof and in the direction of the nearest cell tower provided by your carrier. There is no need to aim an omnidirectional antenna. In situations where installing the antenna on the roof is impractical, you can mount it in the attic, on a wall, or near a window facing the cell tower. Keep in mind that the added obstructions can degrade the signal the antenna will be receiving. As a result, the amplifier will be receiving less signal, which can reduce the coverage area. Step 3: Connecting the Outdoor Antenna to the Amplifier After the antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside your home. This can be done in multiple ways: Drilling a hole into your house Following your satellite TV antenna cable and running the coax cable alongside it and into your house Running the cable through a vent Use a flat window entry cable and run it underneath the window Whichever method you decide to use, it's recommended to put a drip loop in your cable before it enters the house. A drip loop is a low point or a loop on the cable forcing the water to drip off and preventing it from entering your home. Once the cable is inside, connect it to the signal amplifier. Step 4: Installing the Inside Antenna Ideally, the inside antenna should be installed in or near the area where you are experiencing connectivity issues. Cell phone signal booster kits can consist of different types of indoor antennas: Dome Antenna: This antenna is ceiling mounted and will distribute a signal in a 360-degree angle. Panel Antenna: Usually, this antenna is wall-mounted, but it can also be ceiling mounted (make sure it's facing down). Panel antennas distribute a single in a 45 to 70-degree angle, meaning the signal will be strongest in the areas closest to it. Desktop Antenna: These antennas can be placed on any flat surface. Some booster kits, like the weBoost Home Room, consist of a stand-alone desktop antenna, while others, like the SureCall Flare 4G 3.0, or HiBoost Home 4K Plus, feature a 2-in-1 amplifier/antenna combo. When installing the inside antenna, make sure there is at least a distance of 20 feet vertical or 50 feet horizontal between the outside and inside antennas to prevent oscillation, which will cause the booster to shut down. After placing the antenna in the area where you need a better signal, connect the coaxial cable that was included in the box to the antenna and the amplifier (excluding amplifier/antenna combos). Step 5: Power On To complete the cell phone signal booster installation process, connect the power cord to the amplifier and a wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, the green lights on the booster mark the end of poor reception and dropped calls. If at any point in time you wanted to adjust the equipment's location or troubleshoot the amplifier, simply unplug the power cord, and plug it back in after a few seconds. Similar to how you would restart a router to reset your wireless signal. Alternative: Professionally Installed Cell Signal Boosters If the idea of installing a signal booster in your home or small business has you down, we offer a number of signal boosters which include professional installation as a part of the package. weBoost Installed Home Complete - 474445 Buy Now at $1299.99 Buy this Cell Phone Signal Booster If: You want to have your booster professionally installed. You live in a large home with strong outdoor signal and want whole home coverage. You live in a midsize home with weak outdoor signal and want whole home coverage. The weBoost Installed Home Complete is made to cover an entire home. It comes with free professional installation in virtually every zip code in the country. It can cover a large home with decent outside signal or a midsize home with weak outdoor signal. It can give up to 7,500 square feet of coverage with perfect outside signal. Most people will probably see a coverage area of between 3,500 and 5,500 square feet. If you want to cover more than one floor, you should buy more antennas. If you live in a very weak signal rural area you might get about 2,000 square feet of coverage from it. The weBoost Installed Home Complete is the only cellular amplifier we have that comes with free installation right now. If you do not think you can install a signal booster, buy this one. The installation is only available for residential buildings. For commercial buildings, check out the WilsonPro line, and the weBoost Office 300 Installed. weBoost Office 300 Installed Buy Now at $3799.99 Buy this Cell Phone Signal Booster If: You have a large office or commercial space. You want total carrier coverage in your business. You want a booster that's professionally installed. The weBoost Office 300 Installed is a commercial-grade booster for small to medium businesses. It can cover up to 15,000 square feet under best conditions, and comes with professional installation by OnTech. Equipped with a high-gain omnidirectional outdoor antenna and two low-profile indoor antennas, it offers incredible reach to distant cell towers and wider coverage. Whether your business is in the city or the countryside, the weBoost Office 300 Installed ensures reliable connectivity through your office building or in key areas. Commercial Installation Services In addition to WilsonPro installation, our nationwide team also offers Nextivity Cel-Fi installation. How to Install a Car Signal Booster Installing a vehicle signal booster is fast and simple. You won't be needing any tools. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your vehicle, as long as it's properly ventilated. Most people place the amplifier under a seat, but it can also be mounted to a seat. Step 2: Installing the Outside Antenna Most vehicle boosters feature a magnetic mount antenna, making them extremely easy to set up on a car, truck, or SUV. Simply place the external antenna on the roof of your vehicle, and voila. For optimal performance, the antenna should be at least 6 inches away from any windows and at least 1 foot away from any other antennas on your vehicle's roof. Run the cable below a door's weather seal and connect it to the amplifier. Note for new Ford owners or other cars made of aluminum: The antenna will not magnetically attach to an aluminum roof. You'll need to use stickem to attach the outside antenna. Step 3: Installing the Inside Antenna Low-profile antennas are the most common in-vehicle antennas. They can easily be Velcroed vertically or horizontally to the dashboard or a seat. Cradle antennas, on the other hand, are installed on your vehicle's air vent. Regardless of which antenna your booster uses, it must be installed at least 8 inches away from any person. After the antenna has been installed, connect the antenna's cable to the amplifier. Step 4: Power On To complete the vehicle booster's installation, connect the DC power supply to the booster and the auxiliary power outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. How to Install an RV Signal Booster Installing an RV signal booster is not hard. The most difficult step is installing the outside antenna. You'll be needing a Phillips-head screwdriver and an adjustable wrench. Step 1: Installing the Amplifier The amplifier can be placed anywhere in your RV, as long as it's properly ventilated and close to a power outlet. It can be mounted on a wall, placed on a counter, or inside a cabinet. Step 2: Installing the Outside Antenna RV outside antennas need to be securely mounted on the roof. It can be easily attached to the RV's ladder or railing support post. Most RV boosters use omni antennas. For optimal results, mount the antenna vertically, do not mount it horizontally or at an angle. Doing so will degrade the booster's performance. Similar to a home booster, the higher you can get the antenna the better. This will improve the line of sight between the antenna and the cell tower, as well as reduce the number of cell phone signal blocking material. Just make sure the antenna is below the maximum height allowed in your state. Step 3: Connecting the Outdoor Antenna to the Amplifier After the external antenna has been installed, connect the coaxial cable that was included in the box to the antenna and run it inside the RV. This can be done by drilling a hole on the roof or wall and weatherproofing it later, or rerouting the cable through an existing entry point. After connecting the cable to the booster, make sure to secure the cable outside with cable clips or cable tie mounts. Step 4: Installing the Inside Antenna The inside antenna should be installed in the area where you wish to improve your cell signal. RV boosters, like the HiBoost Travel 4G 2.0 RV LTE and the weBoost Drive Reach RV, utilize desktop antennas to improve the signal indoors, while others, like the Cel-Fi Go+ and the SureCall Fusion2Go 3.0 RV 4G, use low-profile antennas or inside whip antennas. Desktop antennas are extremely easy to set up. Simply place the antenna on any flat surface. Low-profile antennas can easily be Velcroed vertically or horizontally to the dashboard or a seat. Inside whip antenna connects directly to the amplifier. For optimal results, make sure it's in an upright position. After placing the antenna in the area where you wish to improve your signal, connect the antenna's cable to the amplifier (excluding the inside whip antenna). Step 5: Power On To complete the RV booster's installation, connect the AC/DC power supply to the booster and the auxiliary power outlet or wall outlet. It will take a few seconds for the booster to configure itself. Once it's done, if all the lights are green, you're good to go. Contact Us Signal Boosters is a leading provider of FCC-approved cell phone signal boosters for homes, vehicles, and commercial buildings. We believe everyone should enjoy great cell phone signal. That is our goal. We provide lifetime support and 2-3 year warranty on all of our signal boosters. Call us, and we will assist with any issues you might be experiencing with poor cell service. Contact us today, or call us at 1-800-470-6777. Interested in Learning More? Check Out Our Cellular Info Hub / WiFi Info Hub Are you tired of dropped calls and slow data speeds in your home? If you're a homeowner who's handy and tech-savvy, you can take matters into your own hands and install a cell phone booster for home to improve your cellular signal. In this comprehensive guide, we'll walk you through the process of choosing and installing a cell phone signal booster in your home. Let's get started! What Does a Signal Booster Do? Cell phone signal boosters are devices designed to amplify weak cellular signals, providing better coverage and improved call quality in areas with poor reception. They can be particularly useful for homeowners living in rural or remote areas, where cell towers may be few and far between. Cell Phone Booster Installation & How-to Guide 1. Prepare for Installation Before you begin the installation process, gather all necessary tools and equipment and carefully read the manufacturer's instructions. Familiarize yourself with the various components of the signal booster system, including the outside antenna, amplifier, inside antenna, and coaxial cables. Ensure that you have access to a power source for the amplifier and that you have permission to mount the outside antenna if you're in a rental property or have any homeowner's association restrictions. 2. Mount the Outside Antenna Properly mounting the outside antenna is essential for maximizing your cell phone signal booster's performance. The following steps provide a detailed guide on how to mount your outside antenna effectively: a. Choose the antenna type: Outside antennas come in two main types: omnidirectional and directional (also known as Yagi). Omnidirectional antennas capture signals from all directions, making them suitable for situations with multiple carriers or towers in different directions. Directional antennas, on the other hand, focus on a specific direction and offer better signal gain. This makes them ideal for situations where the signal is coming from one direction, or you need to target a specific tower. b. Determine the best location: To find the optimal location for your outside antenna, use your smartphone or a signal meter to identify the areas with the strongest signal outside your home. In general, higher locations with a clear line of sight to the cell tower will provide better signal reception. Avoid mounting the antenna near large metal objects or other obstructions that could interfere with the signal. c. Mount the antenna: Once you've identified the best location, securely mount the antenna using the provided mounting hardware. For a roof mount, you may need to drill pilot holes and use brackets to secure the antenna. For a pole mount, you'll need to attach the antenna to a sturdy pole using clamps or brackets. Ensure the antenna is securely fastened and properly oriented (for directional antennas) to avoid any signal issues or potential damage. d. Ground the antenna: To protect your signal booster system and your home from lightning strikes or electrical surges, it's essential to ground the outside antenna. Attach a grounding wire to the antenna's grounding point and connect it to a suitable grounding source, such as a ground rod or your home's electrical grounding system. Follow local electrical codes and regulations to ensure proper grounding. e. Run the coaxial cable: After mounting the antenna, run a high-quality coaxial cable from the antenna to the location where you plan to install the amplifier. It's crucial to use weatherproof coaxial cable designed for outdoor use to prevent signal loss and damage from the elements. Secure the cable along its path using cable clips or ties, and make sure to avoid sharp bends or kinks that could affect signal quality. f. Seal cable entry points: When passing the coaxial cable through an exterior wall or other entry points, ensure that you properly seal the opening to prevent water, insects, or other debris from entering your home. Use silicone sealant or weatherproof cable entry plates to create a watertight seal and maintain the integrity of your home's exterior. With the outside antenna properly mounted and connected, you can now move on to installing the amplifier and inside antenna(s) to complete your cell phone signal booster system. 3. Run the Coaxial Cable Running the coaxial cable is a crucial step in the installation process of your cell phone signal booster system, as it connects the outside antenna to the amplifier and the inside antenna. Proper installation and routing of the cable are essential to maintain signal quality and minimize signal loss. Consider the following factors when running the coaxial cable: a. Choosing the right coaxial cable: The type and quality of the coaxial cable can have a significant impact on the performance of your signal booster. It's important to use the appropriate cable for your specific booster model and installation requirements. Higher quality cables, such as RG-6, LMR-400, or RG-11, can reduce signal loss and improve overall performance. Consult your booster's manual for recommended cable types and lengths. b. Planning the cable route: Before running the cable, plan the route that it will take from the outside antenna to the amplifier and inside antenna. Try to minimize the cable's length and the number of bends or turns, as these can increase signal loss. Ensure that the cable's route avoids sharp edges, extreme temperatures, or sources of electromagnetic interference that can degrade the signal. c. Getting the cable inside: To bring the coaxial cable from the outside antenna to the inside of your home, you'll need to find a suitable entry point. This can be an existing hole or conduit, a small drilled hole through an exterior wall, or a vent or window. Use appropriate cable grommets, feed-through bushings, or weatherproofing to seal the entry point and protect the cable from damage and moisture. d. Securing the cable: As you run the coaxial cable, use cable clips, ties, or straps to secure it in place and keep it organized. Avoid kinking or tightly coiling the cable, as this can cause signal loss and damage. Maintain a safe distance from power lines, electrical fixtures, and other sources of interference. When routing the cable through walls or ceilings, use appropriate cable supports and protectors, such as cable conduit or raceways. e. Connecting the cable: Once the cable has been run, connect it to the outside antenna, amplifier, and inside antenna according to the booster's manual. Ensure that the connectors are securely fastened and that there is no strain on the cable or connections. Use a signal meter or smartphone app to test the system and verify that the cable connections are functioning properly. By carefully planning, routing, and securing the coaxial cable, you can optimize the performance of your cell phone signal booster system and ensure a strong, reliable connection between the outside and inside antennas and the amplifier. 4. Install the Amplifier The amplifier is the heart of your cell phone signal booster system. It takes the weak signal received by the outside antenna, amplifies it, and then rebroadcasts it via the inside antenna. To install the amplifier, follow these steps: a. Choose a location: Find a suitable location for the amplifier, preferably in a well-ventilated area that's centrally located between the outside and inside antennas. This will help to minimize cable runs and ensure the best performance. Make sure the amplifier is protected from extreme temperatures, moisture, and direct sunlight. b. Mount the amplifier: Mount the amplifier securely to a wall or other stable surface using the provided mounting brackets or screws. Ensure that it is mounted level and securely fastened to prevent any movement or vibration that could affect performance. c. Connect the cables: Connect the coaxial cables from both the outside and inside antennas to the appropriate ports on the amplifier. It's essential to use high-quality cables to minimize signal loss and ensure the best performance. Make sure the connections are tight and secure to avoid signal issues. d. Power up the amplifier: Plug the amplifier's power supply into a nearby electrical outlet and connect it to the amplifier. Ensure that the power supply is not located near any sources of interference, such as other electronics or large metal objects, that could affect the signal quality. Turn on the amplifier and allow it to initialize before testing the system. With the amplifier installed and connected, you can now move on to adjusting and testing the system to ensure optimal performance and coverage throughout your home. 5. Inside Antenna Placement Proper inside antenna placement is crucial for ensuring optimal signal coverage and performance of your cell phone signal booster system. To determine the best location for your inside antenna(s), follow these steps: a. Identify coverage areas: Start by identifying the areas in your home where you need improved cell signal coverage. These might include living areas, bedrooms, or home offices where you frequently use your cell phone. Consider the layout of your home, the location of walls and other obstructions, and the construction materials used, as these factors can impact signal propagation. b. Choose the antenna type: Inside antennas come in two main types: panel and dome. Panel antennas are directional and can be mounted on a wall or ceiling to provide coverage in a specific area or direction. Dome antennas are omnidirectional and distribute the signal evenly in all directions, making them suitable for central locations with an open layout. c. Determine optimal placement: Based on the coverage areas you've identified and the type of antenna you've chosen, determine the best location for your inside antenna(s). For panel antennas, select a location on a wall or ceiling that faces the area you want to cover. For dome antennas, choose a central location with a relatively open layout to ensure even signal distribution. Avoid placing the antenna near large metal objects, electronic devices, or other sources of interference that could affect signal quality. d. Mount the antenna: Securely mount the inside antenna using the provided mounting hardware. For wall-mounted panel antennas, you may need to drill pilot holes and use screws or anchors to secure the antenna. For ceiling-mounted dome antennas, attach the antenna to a sturdy ceiling surface using the provided hardware, and ensure that it's level and secure. If necessary, you can use extension cables to position the antenna at the desired location. e. Maintain separation distance: To avoid oscillation or feedback between the outside and inside antennas, maintain a minimum separation distance between them, typically around 50 feet vertical or 20 feet horizontal, depending on your specific booster model. Consult the booster's manual for recommended separation distances. f. Connect the antenna to the amplifier: Run a high-quality coaxial cable from the inside antenna to the amplifier. Keep cable runs as short as possible to minimize signal loss, and avoid sharp bends or kinks that could affect signal quality. Connect the cable to the appropriate port on the amplifier and ensure that the connection is tight and secure. With the inside antenna properly placed and connected, you can now move on to testing and adjusting your cell phone signal booster system for optimal performance and coverage. Number of Inside Antennas Depending on the size of your home and the desired coverage area, you may need to install multiple inside antennas. If you're using a signal booster system with multiple inside antennas, follow the manufacturer's guidelines for proper spacing and placement to avoid interference and ensure optimal performance. Adjusting and Testing the System With all components installed, power on the signal booster system and allow it to initialize. Using your cell phone, test the signal strength in various areas of your home to ensure even coverage. If necessary, adjust the outside antenna's orientation, the inside antenna's location, or the amplifier's settings to achieve the best results. Remember to check for oscillation and overload issues, as these can negatively impact the performance of your cell phone signal booster. Follow the manufacturer's troubleshooting steps if you encounter any problems during setup. Troubleshooting Your Cell Phone Signal Booster Occasionally, you may encounter issues with your cell phone signal booster that require troubleshooting. Here are some common problems and potential solutions: Oscillation Oscillation, also known as feedback or looping, is a common issue that can occur in cell phone signal booster systems when the inside and outside antennas are too close to each other or improperly oriented. This can lead to reduced signal quality and booster performance, or even cause the system to shut down automatically to prevent damage. To understand and address oscillation, consider the following factors: What is oscillation? Oscillation occurs when the amplified signal from the inside antenna is picked up by the outside antenna, creating a feedback loop similar to the screeching noise you hear when a microphone is too close to a speaker. This feedback loop can cause the booster to over-amplify the signal, resulting in poor performance and potential damage to the system. Causes of oscillation The main cause of oscillation is insufficient separation between the inside and outside antennas. Other factors that can contribute to oscillation include improper antenna orientation, antenna signal overlap, and strong nearby cell signals that cause the booster to amplify an already strong signal. Preventing oscillation To prevent oscillation, ensure that the inside and outside antennas are adequately separated. Consult the booster's manual for recommended separation distances. Additionally, make sure that directional antennas are properly oriented, with the outside antenna pointing towards the cell tower and the inside antenna pointing towards the desired coverage area. Detecting oscillation Most cell phone signal boosters have built-in safeguards to detect oscillation and either reduce the system's gain or shut down automatically to prevent damage. Check the booster's LED indicators or consult the manual for specific error codes or warning signs related to oscillation. You can also use a signal meter or smartphone app to monitor signal levels and detect any sudden changes in signal strength that may indicate oscillation. Troubleshooting and resolving oscillation If you suspect oscillation, first verify the separation distance between the antennas and adjust if necessary. Ensure that directional antennas are properly oriented, and consider adjusting their positions to minimize signal overlap. If the problem persists, try reducing the booster's gain settings or installing additional shielding or attenuation to reduce the signal strength between the antennas. By understanding and addressing oscillation, you can ensure optimal performance and coverage from your cell phone signal booster system and avoid potential damage or system shutdowns. Overload Overload, also known as signal overload or input overload, is a potential issue that can occur in cell phone signal booster systems when the outside signal being received by the booster is too strong. This can lead to reduced signal quality and booster performance, or even cause the system to shut down automatically to prevent damage. To understand and address overload, consider the following factors: What is overload? Overload occurs when the outside signal strength received by the booster exceeds the maximum input level that the booster can handle. This excessive signal strength can cause the booster to over-amplify the signal, resulting in poor performance, interference, and potential damage to the system. Causes of overload The main cause of overload is a very strong outside signal, often originating from a nearby cell tower or other wireless communication infrastructure. Other factors that can contribute to overload include improper antenna orientation, which can cause the antenna to receive signals from multiple cell towers, and strong signals from other wireless devices or sources of radio frequency interference. Preventing overload To prevent overload, ensure that the outside antenna is properly oriented towards the cell tower serving your carrier, and adjust the antenna's position if necessary to reduce signal strength from other sources. Consider installing a signal attenuator or shield to reduce the incoming signal strength if it's too strong for your booster. Additionally, consult your booster's manual for recommended input signal levels and ensure that your system is operating within those parameters. Detecting overload Most cell phone signal boosters have built-in safeguards to detect overload and either reduce the system's gain or shut down automatically to prevent damage. Check the booster's LED ind